
# Dad Popup Card

+



### **Materials:**

Copper Tape - 1/4"
Battery - CR2032 - 3v
Transparent Tape
LED - 5mm or 10mm
LilyPad Button Switch
Circuit Stickers (optional)

# Time Required:

Tools:

Scoring Tool

X-Acto Knife


Scissors


30 minutes

# Steps:

- Fold template
  along line. Using
  a scoring tool
  can help.
- Apply copper tape to trace line.
  Smooth with finger.
  Allow a gap for LED and switch
- Fold copper tape at all corners. Try to maintain a continuous strip with no cuts.
- Place battery on top of copper tape with negative (-) facing down.
- Stick end of copper tape to the top of battery (+)
- Bend legs of LED at a 90' angle.
  Use clear tape to secure LED to copper tape.
  Long leg of LED goes on positive.
- Mount LilyPad switch using clear tape. Make sure there is a gap in the copper tape below switch.

# Dad Popup Circuit





## Materials:

# Tools:

Template

Scissors Scoring Tool X-Acto Knife

# Time Required:

30 minutes

# Steps:

- Cut all of the SOLID lines along the word DAD.
- Fold all DOTTED lines on top and bottom of popup.
- Fold DOTTED lines on both sides of the popup. Don't fold the middle.
- Place overlay directly over the circuit template.
  The button marked PRESS should line up with the LilyPad switch on template below.

